

USER GUIDE

MagusUke Ukulele Preamp


MagusUke Quick Start

1. When the output line is connected to MagusUke, it will start automatically. When the output line is pulled out, it will shut down automatically.

MagusUke Controls

1. Volume - For the cleanest signal, set the volume knob as high as possible, without causing distortion or feedback.
2. Tone - Push tone to adjust high frequency.
3. Tuner - Play a single note by your instrument, the string number and note name will shown on the display.

The light and indicator change as following:



Meter In Initial
Position: Tuner Standby



Meter In Center:
The Note Is In Tune



Meter Points Left:
Note Is Flat (Too Low)



Meter Points Right:
Note Is Sharp (Too High)

Specification

Nominal Input Level: -20dBV

Input Impedance: > 1M Ohm

Output Impedance: < 2K Ohm (20Hz ~ 20KHz)

Nominal Output Level: -12dBV

Tone control:

Min: [-20dB at 80Hz, 8dB at 10KHz]

Max: [-10dB at 80Hz, 12.5dB at 10KHz]